

Contents

I. Safety and precautions.....	
II. Cell phone outline.....	
III. Preparations.....	
IV. Description of cell phone.....	
V. Basic operation of cell phone.....	
VI. Operation menu function.....	
VII. Operating instructions of English editor.....	
VIII. Application of USB storage function.....	
Precautions before using.....	
IX. Appendix I.....	
Troubleshooting.....	
X. Appendix II.....	
Abbreviations.....	

I, Safety and Precautions

To use your cell phone safely and effectively, please read the following information before use:

- ✧ Please turn off your phone when you are near a chemical plant, a gas station, an oil depot or other explosives.
- ✧ Please keep your phone out of the reach of children.
- ✧ To ensure safety, please use earphone during driving; Otherwise, unless emergency, you should make a call after parking your car by the roadside. Do NOT use the phone during driving at high speed.
- ✧ Do NOT use your cell phone while in a plane. Please check whether Auto Power On is set or not before board.
- ✧ Do not use your cell phone in a hospital to avoid interference with the normal operation of medical equipment which may result in a medical accident. If the cell phone is used near a pacemaker, audiphone and some medical electronic equipment, you should pay special attention to that the cell phone may interfere with these devices.
- ✧ Auxiliaries and accessories not provided by us are excluded from the guarantee.
- ✧ Do not dismantle your cell phone by yourself. In case of a failure, please contact the service station specified by us.

- ❖ Do NOT charge your phone with no battery. Please turn off your phone before removing the battery; otherwise, the phone memory may be damaged.
- ❖ The phone should be charged in the environment which is well-ventilated, and should be kept away from the inflammables and explosives.
- ❖ To avoid demagnetization, please keep your phone away from magnetic substances, such as magnetic disk, credit card, etc.
- ❖ Please be sure the phone isn't exposed to any liquid. If this situation occurs, please remove the battery and contact the service station specified by us.
- ❖ Please use your phone in the environment which is neither too hot nor too cold, and do not expose your phone to the strong sunlight or use in high-humidity environment.
- ❖ Do NOT use liquid or wet cloth with strong detergent to clean your phone.
- ❖ Your cell phone has photo and record functions, so please use these functions following the related laws and regulations. You may violate the law and regulation if taking photo and record without authorization.
- ❖ Do not throw, drop or hit the cell phone during use to avoid damage to the housing or the elements inside the phone.
- ❖ Do NOT dispose the worn battery as common domestic rubbish. Please dispose the worn battery according to the specified instructions where the disposal of a worn battery is clearly specified.

〈Note〉 : 1. The Company won't undertake any responsibility for any consequences caused by failure to observe the above-mentioned suggestions or improper applications.


2. The provided cables are only applicable to this type of mobile phone and the provided charge; you can also connect the phone to the PC by a USB cable to charge the phone. Do Not charge the phone by any other mode.

If any content described in this manual goes against that of your cell phone, please subject to the real cell phone.

The Company is entitled to modify the manual at any time without further notice.

II. Cell Phone Outline

2.1 The following is the view of the phone :



III. Preparations

Installation of your SIM card

You can apply for two different numbers offered by two network providers and get two SIM cards (users identify cards).

With those two SIM cards, you can use various functions of this cell phone. Many parameters required for communications are stored in the SIM cards. Personal data, including the PIN (personal identification number), phonebook, SMS and other extra system services can also be stored in the SIM cards.

Warning : Do NOT twist or scratch the SIM card and expose it to static electricity, dust or water. If you lost your SIM card, please contact your network operator for help.

To install your SIM cards, please turn off your cell phone first, remove the back cover, and insert the SIM cards into the SIM card slots at the back of the phone.

Please install the SIM cards as shown below :



Note : The SIM card is a small object, please keep the card out of the reach of the child to avoid swallowing the card by accident! Do not touch the metal surface of the SIM card and keep it away from electromagnetism to avoid loss and damage on the data. You will not be able to connect to the network if the SIM card is damaged.

Installation of memory card

The phone supports T-FLASH card as to expand the memory space. Please install or take out the memory card as per the following picture after shutting down the phone.



Note : The T-FLASH card is a small object, please keep the T-FLASH card out of the reach of the child to avoid swallowing the card by accident!

Tip : The phone supports a memory card with capacity up to 4GB. It is recommended that only the attached standard TF card and other TF cards of well-known brand like SanDisk and Kingston are used. Other TF cards may be not compatible with the phone.

Installation of battery

Please use the original-packaging battery and accessories. Store the battery well if it is not used.

Please install the battery at shut down status.




Note : Please follow the correct procedures as shown in the figure to prevent damage to the battery contact points.

Charge the battery

The new battery must be fully charged and discharged for several times to reach its best performance.

Charge as soon as possible when the power is used up as over-discharge will damage your battery.

phon



When charging, if the phone is switched on, the power quantity icon at the top right corner of the screen will twinkle and will stop twinkling and fully display when the battery is fully charged. If the phone is switch off, an icon will appear at the screen to show the battery is in charging and icon will be static and OK will be display on the screen when the battery is fully charged.

Note : A little heating while charging is normal.

Use of battery

The performance of the battery is affected by multiple factors including your wireless loading network configuration, signal intensity and temperature when using the phone, the function or settings you selected, the accessories adopted for cell phone and other applied program modes.

To optimize the performance of the battery, please do as following regulations :

- ✧ New battery or a battery is left unused for a long time should be charged for a long time ;
- ✧ Keep the temperature at or near room temperature when charging ;
- ✧ The battery may require longer time to be full charged after being used for a long time and this is normal. If the call time becomes too short, you may need to buy a new battery produced by Company or authorized by our company. Unqualified battery or accessories may damage your phone and even cause danger !
- ✧ If the battery is left unused for a long time or the power is too low, it may require longer time for the charging interface to appear, please wait patiently.

Note :1, For your safety and environment, please do not throw away the battery everywhere.

- 2, When the capacity of battery is too low, the phone will alarm “capacity too low”. Cell phone should be charged in time.

Warning: Explosion, fire or personal injury may be caused by any type of

battery short-circuit !

PIN

PIN1 code: Personal identification code used to enter SIM card and to prevent others to use the SIM card without your permission. If PIN1 code safeguard function of your cell phone has already been started, the system will display “Enter SIM card 1/2 PIN” to enter when switching on the phone. * will be displayed instead of the PIN1 you entered. You can get PIN1 from your network provider together with the SIM card.

PIN2: The personal identification number use for special functions such as charging function provided by the network.

PUK and PUK2 (8 digits)

A PUK is required to change the PIN. To change the PIN2, you need to use PUK2 (personal unlock code). If PUK is not provided together with the SIM card, please ask for it from your network provider.

〈Warning〉 : If the PIN code is entered continuously three times, the SIM card will be locked in. Please consult the network supplier right away to look for deciphering. Unauthorized deciphering may cause permanent failure to the SIM card.

IV、 Description of Cell Phone

Dialing key

Make or answer calls.

Short pressing the dialing key can enter call log under standby status.

Hang-up key & on/off key

Hang-up or reject a call.

Long press the key to switch off the phone under standby status.

Long press the key to switch on the phone when the phone is switched off.

Direction keys

Move the bar or cursor.

Enter appointed shortcut under standby status.

OK Key

Confirm an operation in menus.

Side keys

Volume up/down when call or playing MP3.

Regulate key tone under standby mode.

Number keys


Input numbers or characters.


Long press the number keys 1to 9 to quick-dial while standby.

Long press the # key to mute and quit mute under standby mode.


Short press the * key repeatedly or long press it to enter “P”, “+” or “W” characters under dialing interface.


Icons on screen in standby status


 SIM card 1 Antenna


 SIM card 2 Antenna


 Alarm clock activated


 SIM card 1 SMS

 SIM card 2 SMS

 SIM card 1 MMS


 SIM card 2 MMS


 Battery


 Ringing; this icon varies according to different altering methods. Other


icons include:

 Vibration then ring

 Vibration and ring

 Vibration

 Mute (only LED)

 Missed calls in SIM card 1

 Missed calls in SIM card 2



Keypad locked



SIM card 1 GPRS



SIM card 2 GPRS



Bluetooth



Call divert activated in SIM card 1



Call divert activated in SIM card 2

Languages & Input Methods

English input method is provided in your phone. For details, please refer to chapters related to language editing, where you can learn different input methods and how to switch between them.

Incoming Call alert method

The built-in vibrating motor and buzzer in your phone provides the following alerting modes:

Ringing

Vibrating

Vibrating and ringing

Vibrating then ringing

Only lighting

Descriptions of nouns

❖ **Making a national call**

The simplest way to make a domestic call is to input a phone number by

numeral keys and press the dialing key. If call by SIM card 1, the screen will display “SIM Card 1 Dialing”, and if called by SIM card 2, the screen will display “SIM Card 2 Dialing”.

Call status will display on the screen when the call is answered.

Press the hang-up key to end the call.

Make domestic calls: zone number + phone number + dialing key.

The left soft key can be set the dialing key of SIM card 2. This function be activated in the menu of “Call center/SIM card 2 call settings/SIM card 2 dialing settings/Left soft key”.

❖ **Making an international call**

To make an international call, long press or repeatedly short press the * key until the symbol “+” is displayed on the screen. This allows you to make an international call without knowing the prefix number of that country (e.g. China is +86).

Then input the country code and the complete phone number. The country code is subject to convention, e.g. Germany is 49, Britain is 44 and Sweden is 46, etc.

Make international calls: + country code + complete phone number + dialing key.

❖ **Call extension of a fixed phone**

Extensions of some fixed phones are not accessible directly, in such case,

you need to dial the host number and then the extension number. Simply insert the letter “P” between the host number and the extension number and you can call the extension. You can input a “P” by long pressing or repeatedly short pressing the * key.

Call extension of a fixed phone: phone number + P + extension number + dialing key.

❖ **Make emergency calls**

In any country where digital GSM is used, you can make an emergency call if your phone is covered by the network (you can know about this by checking the signal strength indicator bar at the upper corner of the display of the cell phone). If your network operator does not provide roaming service in that area, the screen will display "EMERGENCY CALLS ONLY", telling you that you can make this kind of call only. If you are in the coverage of the network, you can make emergency calls even if your SIM card is not inserted in.

* In some areas, the 112 (emergency call) service is provided by the network operator. If there is anything abnormal, contact your network operator!

❖ **IMEI**

International Mobile Equipment Identity. You can see the bar code label printed with this number at the back of the cell phone after you have turned off the cell phone and remove the battery. This number is also stored in the cell

phone, and can be displayed when you enter "*#06#" on the screen dial interface.

V、Basic operation of cell phone

Switch on

Press and hold on “ON/OFF” to start up the cell phone. If no password settings are given for the SIM card and cell phone, the phone will search for a network automatically, and when the cell phone registers a network, the name of the network supplier will be shown on the screen. You can now answer or make a call.

If the display indicates “Insert SIM card 1” or “Insert SIM card 2” after the start-up, please power off your phone, and check whether your opposite SIM cards have been installed correctly or hasn't yet been installed or not.

After plugging into a SIM card, the phone will automatically check SIM card for availability, then the display screen will indicate the following prompts in sequence :

- 1) “Enter phone lock password” —— if you have started up the phone lock (default password: 1122.)
- 2) “Enter SIM card 1/2 PIN” —— if you have started up the SIM card 1/2 lock.
- 3) “No service” —— it represents the register network failure, and you can't call at this time.
- 4) “Emergency Call” —— it allows to call 112.

- 5) “Search” —— the phone is searching a network, until it finds out a suitable service network.
- 6) The screen displays the network operator name – it represents the network register success.

If only SIM 1 card is installed and the current mode is “SIM card 1 only”, the screen will display the name of SIM card 1 provider only and that “SIM card 2 is off”; if only SIM card 2 is installed, the screen displays in reverse. If only SIM card 1 is installed and the current mode is “two cards on”, the screen will display the name of SIM card 1 provider only and that “Please insert SIM card 2”; if only SIM card 2 is installed, the screen displays in reverse.

Switch off

If you want to shut down the cell phone, please long press ON/OFF key, and after the screen displays the power off animation, the cell phone will shut down. Please don't shut down the phone directly by dismantling the battery, and if you do like this, it is easy to damage SIM card and may cause loss of some information.

Making a call

- ◇ Enter the phone number in standby status, and press the calling key to call. If you want to hang up or cancel the call, please press the hook up/cancel key ; When the phone is connected, you can see the holding time on the screen.
- ◇ Use the phonebook to make a call: Search the name/phone number saved in the phonebook, and press the calling key to call.

- ✧ Redial the latest phone number :Press the calling key in standby status to search the latest list of phone number or name. Roll over to the number or name, then press the calling key.

Adjusting the receiver volume

During a call, you can press side keys to adjust the receiver volume.

Answering a call

When there is a coming call, it will indicate in a mode of ring, vibration, vibration and ring , ring after vibration or lighting according to the setup of cell phone.

To answer a call, press the calling key.

To reject a call, press on/off key.

If you have applied for calling number identification service, the calling number will show on the screen. If this number has already stored in the phonebook, the corresponding name of this number then will show on the screen.

If the call is to SIM card 1, “Call to SIM Card 1” will display in front of the number or name.

If the call is to SIM card 2, “Call to SIM Card 2” will display in front of the number or name.

Speed dial

The phone provides 8 speed buttons, and you can define the phone numbers corresponding to these buttons. So, as long as you long press [2 to 9] keys in standby

status, you can call speedily; [1] key is specially used for the speed dial of voice mailbox number.

<Note> : To speed dial, you have to press and hold on/press a key for 2 seconds and above, and if you haven't designated the speed dial function for that key, then you can't be successful for the call.

Sending DTMF signal

When you have set up the DTMF signal sending function, if you press the digit key and * and # key of the keypad during the period of conversation, it will be sent out in the form of DTMF signal to the other party. If you don't start up this function, you can't carry out the extension number calling, etc. functions probably.

Call Hold

If you have applied for the value adding of call waiting, the following function menu may appear when you click an entry during conversation :

- ✧ Hold: Temporarily suspend the current conversation, but the conversation channel still under connection.
- ✧ End: End the current connection.
- ✧ New conversation: Enter the dial interface, and make another call.
- ✧ Phonebook: You can enter a phonebook directory.
- ✧ Information: You can enter messages directory.
- ✧ Record : You can record the current calling contents.
- ✧ Background tone : Enable or disable the background tone.

- ✧ Mute/resume: You can switch on/off microphone.
- ✧ Dual-tone multi-frequency, DTMF: You can set up whether to send out a DTMF signal.

Note : Some menu entries just appear under the specific condition, or they need support from the local network, such as: “Hold” and “New conversation”, etc., for detail, please consult the network supplier.

Non-response event

When the cell phone has new unread messages and missed call etc. events, the cell phone will have the corresponding picture or icon prompt, please search these messages in time.

Connecting to voice mailbox

Your cell phone allows you to divert the incoming call to the voice mailbox, then, you will receive a notice concerning the voice messages (the center number of voice mailbox should be set up properly in advance).

VI, Operation menu function

1 Messages

1.1 SMS

The SMS function is a network service. You may need to apply to the network operator first before you can send and receive a short message.

Your cell phone supports the short message sending function. Short messages are sent to network SMS center first and then sent to subscribers. If the subscriber does not turn on the phone or cannot receive messages (storage is full), the network will keep this message temporarily. The keeping period will be determined jointly by the message sending user's setting and the service operator.

By using the SMS, the phone can send and receive long messages. Sending long messages may affect the charge for the messages. For details, please contact your service operator.

If the memory for message is full, a twinkling icon will remind you on the screen. You mobile phone support dual SIM card so messages in SIM card 1 and 2 are separately stored. The reminders for full memory of SIM card 1 and 2 will also be given separately. In such case, you need to delete at least one message in the memory of the corresponding SIM card to receive new message.

Note : When you send a short message through SMS network, "Message sent" will be displayed on the screen. That is to say, the phone has sent the message to the message center mailbox set by your phone. But that isn't to say, the specified user has received the message. For more detailed information about SMS, please contact your network operator.

1.1.1 Write Message

You can create a message in this menu.

The phone supports sending a long message having over 160 characters

(character number restriction for common text messages). If a message has more than 160 characters, the message will be divided into two or more messages and sent.

Input method of “English Edit Instruction” can be implemented under message editing interface. The following menu option functions by using left key are provided when you are writing a short message :

✧ **Select SIM card 1/2** : Enter sending method option and send the message.

✧ **Insert** :

1. Templates : Select frequently used phrases from the template and insert into message editing interface.

2. Special Image And Rings : Insert ring tones, picture and images animations and EMS (requiring support network provider).

3. Name and Number : Enter contacts and insert the found (refer to Quick Search in Contacts for searching method) name and number.

Send a message

When a message is composed and the SIM card is selected, you can send the message to the receiver though the following ways:

1. **Send**: Send the message directly.

2. **Add receivers**: Select more receivers to send.

3. **Save** : Save the messages to the Outbox directly.

4. **Send to group** : Send the message to the select group.

Note : Picture message function can be used only when your network operator or service supplier supports the function. Picture messages can be received and displayed only by the phone featuring picture message function. However, the normal display of some picture messages is supported by the phone. For details, please contact the network operator.

1.1.2 Inbox

The received messages are saved in Inbox. You can view all received messages in Inbox. The messages of SIM card 1/2 are separately saved. You can perform the following operations:

- ❖ **Reply:** To replay a received short message.
- ❖ **Delete:** To delete the current message.
- ❖ **Collect the details :** Collect some contents of the current short message, such as the number of user and using website.
- ❖ **Forward:** To forward the current message to the other subscriber.
- ❖ **Copy :** To copy the current short message or all short messages. When the message is stored in SIM cord, it can be copy to the phone storage. When the message is stored in phone storage, it can be copy to the SIM cord.
- ❖ **Transmit All :**You can transmit all messages between SIM cord and phone storage.
- ❖ **Delete some or all :** Delete some or all messages.

1.1.3 Outbox (View the messages of SIM card1/2 stored in Outbox)

The messages that have not been sent successfully are stored in Outbox, and you can implement the relative operations of the messages.

1.1.4 Sent (View the messages of SIM card1/2 stored in Sent folder)

The messages sent successfully will be stored in Sent folder, and relative operations can be implemented. If the function of storing sent messages isn't needed, please select <Store the sent message> of SMS Setting shut off.

1.1.5 SMS setting

Message setting of SIM card 1/2:

You can set some parameters of messages in this menu. Parts of setting menu of SIM card 1/2 are separate.

【Profile setting】 : To set the name of a profile, SMS center number, message validity period, and message type. To send a message, the SMS center number shall be provided.

Note : The number of the SMS center is provided by the network operator. For details, please contact the network operator.

【Common settings】 : Enable or disable delivery report and reply directory.

- ◇ Delivery report : The network reports whether the opposite side has received the message and the time received.
- ◇ Reply path : To transfer the reply path to the network terminal. This function requires the support of message center.

【Memory Status】 : Check memory space use of SIM card or mobile phone.

【Preferred Storage】 : Appoint the directory to save the message (SIM cards or mobile phone).

Template : Edit, delete or create new frequently used phases.

Message Firewall : Enable or disable the blacklist function. You can enter a number in the blacklist. When the function is enable, you phone will reject the messages form the number.

Save Sent Box : Enable or disable store the message be sent successfully.

1.2 MMS

A multimedia message can content character, audio chip and picture. If the size of a multimedia message is over the limit, the phone cannot receive this multimedia message.

The display effect of multimedia messages may vary with different receiving equipment.

Note : You can use this function only when the service is supported by your network operator or service supplier. Only the device featuring multimedia or Email can receive and display a multimedia message. For details, please contact the network operator.

1.2.1 Write message

【To】 : Enter the phone number or Email address of the receiver.

【Cc】 : Enter the phone number or Email address of the receiver for carbon copy.

【Bcc】 : Enter the phone number or Email address of the receiver for blind carbon copy.

【Subject】 : Edit the subject of a multimedia message.

【Edit content】 : Edit the content of the text of the multimedia message.

This includes the following options: :

- ✧ **Done** : Finish the edition of a multimedia message.
- ✧ **Input method** : To select the input method for edition of a multimedia message.
- ✧ **Add picture** : To insert an image to the multimedia message.
- ✧ **Add audio** : To insert an audio file to the multimedia message.
- ✧ **Add video** : To insert a video file to the multimedia message.
- ✧ **Ad attachment** : To insert an attachment to the multimedia message.
- ✧ **Add slide before** : To insert a new slide ahead of the current slide.
- ✧ **Add slide after** : To insert a new slide behind the current slide.
- ✧ **Preview** : To preview the currently edited multimedia message.
- ✧ **Slide timing** : To set the play time of the current multimedia message slide.

1.2.2 Inbox

You can view the received multimedia message in the inbox and perform the

following operations:

- ✧ **View:** To view a multimedia message, and save the attachment of picture or others in the multimedia message.
- ✧ **Reply:** To reply a multimedia message to the sender directly.
- ✧ **Reply by SMS:** To reply through SMS.
- ✧ **All:** To reply all through MMS.
- ✧ **Forward:** To forward the multimedia message to others.
- ✧ **Delete:** To delete current multimedia message.
- ✧ **Delete all:** To delete all multimedia messages in the inbox.
- ✧ **Template :** Store the current multimedia message by template.
- ✧ **Detail:** To view the detailed information of the current multimedia message.
- ✧ **Use item:** Store or dial the number of the received MMS, and edit new multimedia message.

1.2.3 Outbox

You can view a multimedia message failed to be sent. Operation of viewing, forwarding, deleting, deleting all, store in template, viewing message details and using item can be implement.

1.2.4 Drafts

You can save an edited multimedia message in the Drafts, Operation of drafts such as viewing, forwarding, deleting, deleting all, storing in template, viewing

message details and using item can be implement.

1.2.5 Templates

Up to 5 preset multimedia messages have been set in the phone. Operation of viewing, viewing message details, getting new message from template and using item can be implement.

1.2.6 MMS settings

You can set parameters for MMS or view the memory status in this menu. For detailed information on MMS parameters, please contact your network operator.

Compose :

【Compose mode】 : Select the compose mode.

【Picture resizing】 : Enable or disable resizing of picture.

【Auto signature】 : Enable or disable auto signature.

【Signature】 : Input signature.

Send :

【Validity period】 : Set valid time of the message in Message Center.

【Delivery report】 : Enable/disable delivery report.

【Read report】 : Enable/disable read report.

【Priority】 : Set priority to be sent of the multimedia messages.

【Slide timing】 : Set play time of each page.

【Delivery time】 : Set storage time of the message in Message Center. This

setting depends on your network provider and your setting.

Retrieve :

【Home network】 : Immediate, reject, postponed.

【Roaming】 : Same with main network, postponed, reject.

【Read report】 : Send, do not send, inquire.

【Delivery report】 : Enable/disable delivery report.

Filter : Set “Anonymous sender” and “Advertisement” to allow or return messages.

Server profile :

SIM card1

Activate profile

Edit profile :

【Rename profile】 : Enter a name.

【Homepage】 : Edit web address of multimedia center.

【Data account】 : The data account of MMS service.

【Connection type】 : WAP、HTTP.

【User name】 : Edit user’s name.

【Password】 : Edit password.

Memory status : You can check the phone used rate, used and unused space.

1.3 Chat: You can use this text message service (network service) to chat

with others conveniently; view the message logs when chatting. Every message is sent as a single SMS.

1.4 Email

Before using Email, you should set Email options in the “Email Settings” menu first. Through this menu, you can send and receive an Email. Email needs the support of the network. For details, please consult the network operator.

Send and Receive: For sending the desired Email to the specified mailbox and receiving the desired Email from the specified mailbox.

Write Email: For writing an Email.

Inbox: For displaying a received Email.

Outbox: For displaying an Email fails to be sent.

Sent: For displaying the copy of a sent Email.

Drafts: For displaying a draft in the specified mailbox.

Delete all Emails /Marks (folders): For deleting all Emails in the Specified

mailbox, including Inbox, Unsent, Sent, Draft, or Delete all Folders.

Email accounts: For Setting Email connection. The following operations can be performed.

Template: To use default template using email.

1.5 Voice mail server

Voice mail server is a network service. You may apply for this service beforehand. For detailed information and voice mail server number, please contact your network operator.

SIM card 1/2 voice mail server :

- ✧ Edit : To edit voice mail name and server number. Press OK to store your number.
- ✧ Connect to voice :To dial the voice mail server number stored in your voice mail server number list.

Tip: Under the standby condition, you can call the voice mailbox number by long pressing the key "1" after you have set the voice mailbox number.

1.6 Broadcast message

SIM card 1/2 Cell broadcast

Cell broadcast is a service provided by the network operator to send messages such as weather forecast, traffic status, etc. to all GSM subscribers in a specific area.

Note: The realization of the cell broadcast function needs the support of the network. For details, please contact the network operator.

【Receive mode】 : To enable/disable the Broadcast Message.

【Read message】 : When the Broadcast Message has been enabled, the received message can be read after the corresponding server has been enabled.

【Languages】 : To enable/disable the all languages of messages received.

【Channel settings】 : To select, add, edit or delete channel numbers.

2 Phonebook

Each contact saved in your phone contains the following useful information: three phone numbers(mobile phone number, home number and office number), company name, email, fax number, birthday, photo, ring tone, video connect and group(providing five mode: family, friend, important, colleague and others); each contact save in the SIM card only contains name and phone number.

You can input at most 1000 contacts in the contacts saved in the mobile phone , for volume of Contacts saved in SIM card, it depends on the SIM card.

2.1 Quick search

Input the English initial in viewing phone number interface, you can quick

search the number record of the phone number list.

2.2 Search contact

You can find the best matched record by entering the name to be searched and then press “Search” in the Phone book.

2.3 Add new contact

You can add a new entry to the phone or SIM card.

Description :If picture link, ring link, incoming call group, video connecting are set in a record simultaneously, the incoming call group function will be invalid.

2.4 Copy all

You can copy all phone entries in SIM card 1, SIM card 2 and phone to each other.

2.5 Delete

You can delete all entries of the SIM card 1, SIM card 2 and phone, delete entries one by one or selected entries.

2.6 Settings

【Memory status】 : To view the service condition of the phone book storage.

【Preferred storage】 : To select the storage directory of the current number.

【Fields】 : To select the display item in phonebook and add display item in the record interface.

【My vCard】 : To edit or send your name cards.

【Owner number】 : To view and edit the own number

【SOS number】 : To edit SOS number of SIM card 1/2.(SOS number need be supported by SIM card, consult your network operator for details.)

【Caller groups】 : You can set melody, caller picture, video connect and group member, etc. to five groups.

3 Call center

3.1 Call history

SIM card 1/2 calling record, including:

【Missed calls】 : To view the list of missed calls (requiring network service support).

【Dialed calls】 : To view the list of calls you dialed or tried to dial.

【Received calls】 :To view the list of answered calls (requiring network service support)

【Delete call log】 :To delete call history. You can select to delete all numbers in call history, or only delete the numbers listed in Missed Calls, Dialed Calls or Answered Calls.

【Call time】 :

Last call time : To view the duration of the last call.

Total sent : To view the duration of all dialed calls.

Total received : To view the duration of all answered calls.

Reset all time : To reset duration of all calls.

Note: The actual call and service time in the service operator's bill may vary. It depends on such factors as network function, accounting rounding-off and tax. For details, please contact your network operator.

【Call cost】 : Requires the support of the network operator.

Last call cost : To view the cost of the last call.

Total cost : To view the total cost of all calls.

Reset cost : To reset cost record of all calls. (Please enter PIN2 for this function.)

Max cost : To limit the cost within specified amount of pricing unit or currency unit. PIN2 is required for setting the call cost.

Price per unit : This function is supported by your network. For details, please contact your network operator.

【SMS counter】 : View the quantity record of sent and received message.

【GPRS counter】 :

Last sent : To view the volume of data sent in last linkage.

Last received : To view the volume of data received in last linkage.

All sent : To view the volume of data sent in all linkages.

All received : To view the volume of data received in all linkages.

Reset counter : To reset the GPRS counter.

3.2 General call settings

3.2.1 SIM card 1/2 call settings :

【Caller ID】 : Includes Set by Network, Hide ID, and Send ID.

1 Set by network : The number of the phone will be sent as per the default mode when a call is initiated.

2 Hide ID :The number of the phone will not be sent when a call is initiated. If the system doesn't support this function, it may not make a call.

3 Send ID : The number of the phone will be sent when a call is initiated.

Note: This function requires the network support. For details, please contact the network operator.

【Call waiting】 : To set functions like activate/deactivate and enquiry call waiting. During call holding and making multi-party calls, this function should be activated first, and network support is required for the specific implementation of the function.

【Call divert】 : It is a network function that can only be used when you apply for this service of the network operator. The function can divert calls that satisfy the conditions to the other caller's phone number you have designated.

Name	Description
Diver all voice calls	Network will divert unconditionally all your incoming calls.

Divert if unreachable	To divert an incoming calls when your phone cannot be reached (the phone is either switched off or out of network coverage).
Divert if no answer	To divert an incoming call after a certain time period during which the call is not answered.
Divert if busy	To divert an incoming call when you have an active call or other operation is busy.
Divert all data calls	Network will divert call incoming calls (requiring support of network).
Cancel all divert	Cancel all the divert functions.

【Call barring】

1 Outgoing calls

All calls : To restrict all outgoing calls.

International calls : To restrict international outgoing calls.

International calls except to home PLMN : While you are abroad, you can only call the numbers of the country (where you are) and your home country (at which your service supplier is located).

2 Incoming calls :

All calls : To restrict all incoming calls.

When roaming : To restrict all incoming calls except the numbers from your local service area.

3 Cancel all : For canceling call barring. (Password for barring is required.)

4 Change barring password : Apply to the network for changing the password for call barring.

[Line switching] : To choose Line 1 or Line 2.

Note : SIM card 2 supports “SIM card 2 Dialing Setting”. This function is to enable the left soft key as the dialing key of SIM card 2. When you enter a number under standby interface, it will display “Dialing 2” at the left soft key of the screen. Press left soft key to dialing SIM card 2.

[Closed user group] : This feature should be supported by Network, please consult with the local network operator.

Note: Some line conversion should be supported by Network. If your network service provider does not support Line 2 and you have selected Line 2, then calls are unavailable for your mobile phone.

3.2.2 Auto redial :

To set the auto redial as “On” or “Off”. When your dial doesn't succeed, up to 10 redials for you to try to connect a phone number.

3.2.3 Speed dial :

To switch on the speed dial function, and edit the corresponding speed dial number. If the speed dial is "On", then you can long press the corresponding key (2-9) to dial the number designated to the key through the standby interface.

3.2.4 Fire Incoming Call :

【State】 : Open or close the blacklist or red list .

【Black List】 :

A. Single : Add a single number into the blacklist.

B. Group: Add all numbers in an appointed group into the blacklist.

C. No Number In Phonebook :Add all numbers not saved in SIM card or the phone into the blacklist.

【Red List】 :

A. Single : Add a single number into the red list.

B. Group : Add all numbers in an appointed group into the red list.

C. No Number In Phonebook : Add all numbers saved in SIM card or the phone into the red list.

【Time Splitted Firewall】 : You can set a certain period to enable the firewall.

3.2.5 Connect Vibration : On / Off function to connect the vibration prompted.

3.2.6 Background sound : You can set background sound during a call

3.2.7 Magic Call: To change the answering call option. User can set it as Normal, Male, Female, and Kiddie.

3.2.8 Call Time Setting :

【Call time display】 : Display the lapsed time during a call.

【Call time reminder】 : During a call, a sound or a periodic tone sounds every minute to keep you informed of the call duration.

【Auto quick end】 : You can set a limit time. If this function is enabled , the phone will hang up automatically when the call time reaches the set time limit.

Note: Some settings need the support of the networks. For further information, please enquire the network operators. For example, the call restrictions, which need the support of the local network and the setting of the SIM card, could be effective after that.

4 Settings

4.1 User profiles :

Various profiles are provided for your phone. Personalize your phone according to your preference, and then start a profile desired. The profiles available are General, Meeting, Outdoor, Indoor, Headset, Bluetooth and Saving.

In each profile, you can set one of the following options:

Tone setup : To set the tone for incoming calls of SIM card 1/2, alarm, power-on (except Bluetooth mode), power-off, messages of SIM card 1/2 and key press.

◇ **Volume** : To set the volume of ring tone and key tone.

- ✧ **Alert type** : Includes Ring, Vibrate, Vibrate and Ring, Vibrate then Ring, only light.
- ✧ **Ring type** : To set the ring type, including Single, Repeated and Ascending.
- ✧ **Extra tone** : Includes four types, Warning, Error, Camp-on, and Connect.
- ✧ **Answer mode** : Provides any key answer mode.
- ✧ **Status LED calling** : To set the color of coming calling LED.

After personalizing, choose "Activate" to confirm the settings, and the corresponding profile will be activated.

Note: The phone automatically switches to the Headset mode when the headset is plugged, and it restores to the previous mode when the headset is unplugged.

The phone automatically switches to the Bluetooth mode when the Bluetooth device is connected, and it restores to the previous mode when the device is unconnected. Long press the "#" key when the phone is in the standby state to switch the phone to the Mute mode. Long press it again will restore to the previous mode.

4.2 Shortcuts :

You can set a shortcut as needed, including:

4.2.1 Edit shortcuts :

Select any one shortcuts and press the left soft key<option>, the following operations can be implement:

- ✧ **Add:** To add a new shortcut menu.

- ✧ **Edit** : Set one function from the function list to replace the selected shortcut.
- ✧ **Delete** : To delete the selected shortcut menu.
- ✧ **Delete all**: To delete all shortcut menus set.
- ✧ **Disable**: To close all selected shortcut menus.
- ✧ **Change order**: To change the order of shortcut menus.

4.2.2 Dedicated key :

You can appoint the shortcuts of direction keys. Press a key to use the corresponding function under standby interface.

4.3 Display settings:

4.3.1 Display characteristic

- ✧ **Wallpaper** : Set the background picture in standby screen interface.
- ✧ **Screen saver** : Set Standby on / off screen, and start the waiting time.
- ✧ **Show Time and date** : Can be started up/ down at the time and date in standby screen
- ✧ **Show owner number** : Can be on / off standby at the interface shows that the Phone ID information.(caution: the local number required in the phonebook menu settings, and necessary support to the use of SIM cards)

4.3.2 Greeting text

- State** : To set the greetings on the main screen when the phone is powered on.
- Greeting text** : Press <edit> to edit the greeting text.

4.3.3 Misc. settings

Set the brightness and bright time etc. Enable or disable LCD backlight and Signal LED.

4.4 Phone Setup :

4.4.1 Mode set:

Dual cards enable : Open card 1 and card 2

Only SIM card 1: Open card 1

Only SIM card 2: Open card 2

Flight Mode: All network functions will get deactivate, when flight mode function is used.

4.4.2 Set time/date: To set the current time, date and the display format.

✧ **Set the city :** To set the home city.

Note: This option needs application together with the auto time renewal, and needs the network support for the operation of auto time and date renewal.

✧ **Set time/date:** To set the current time and date.

✧ **Set format:** To set the time and date display format.

Time format : Select 12 hour mode or 24 hour mode ;

Date format : Set date display format.

Note : It is required to reset the time again when you load battery again or switch on the phone again after charging the battery if you remove the battery from

the cell phone or if the battery has already been exhausted for a very long period

4.4.3 Schedule power on/off : To set the designated phone On/Off time.

Caution: In particular area (such as airplane compartment) forbidding the use of a cell phone, you shall confirm that the Schedule Power On/Off function is disabled to avoid an accident.

4.4.4 Language: To select the used language for the phone.

4.4.5 Preferred input methods : To set the default input method according to your operation habit.

Note: Please consult your network operator or service provider that if provide this service and more information.

4.4.6 Handwriting : Set the style of handwriting, including handwriting speed and handwriting pen's color, etc.

4.4.7 Auto update of date and time : Enable or disable auto updating of date and time.

4.4.8 Style Setting: User can choose style settings to view menu & submenu folders in this setting.

4.5 Pen calibration : You should pen calibration, when it isn't accuracy that the handwriting pen knocks on some position. The screen should pen calibration termly.

4.6 Network Setup :

4.6.1 SIM card 1/2 Network Setup

Name	Description
Network selection	New Search: To search the network again.
	Select network: The phone only load the appointing network. When the network can't work, the phone won't register other network
	Search mode: Auto/Manual.
Preferred network	To select the preferred network.

4.7 Security setup :

4.7.1 SIM card 1/2 security setup

4.7.1.1 SIM card 1/2 lock : To unlock or lock SIM (PIN).

4.7.1.2 Fixed dial : This function may need the support of SIM card and network operator. When this function is activated, you can only dial the fixed numbers in the fixed dial list. To activate the fixed dial, enter the PIN2.

4.7.1.3 Barred dial: To unlock or lock restrictions on all or partial calling functions. (This function requires the support of the SIM card, and SIM card 2 don't support this function.)

4.7.1.4 Change password : Change the PIN/PIN2 password of SIM card 1. PIN (PIN1) and PIN2 code can be get from your network operator.

Antitheft: To track the cellphone in case of lost or stolen using this function .User need to activate this function &make the settings.

4.7.2 Phone lock : This function allows you to lock/unlock your phone. You can enable/disable your phone by entering password. When the phone is locked, it will require you to enter the password when switching on. Note: the default password is “1122”.

4.7.3 Keypad lock: To unlock or lock the keypad. The time for locking keypad can be set.

4.7.4 Change Password: The default password “1122” of phone, message, phonebook, calling records and privacy protection can be changed as the desired password of 4 to 8 digits.

4.7.5 Privacy Guard: Includes protection for phone book, message and call history. If this function is enabled, corresponding menu or content will be locked. For access, enter the password. The default password is “1122”. You can change the password in the menu of changing password.

4.7.6 SIM Hide: Hide/show SIM card 1/2 information such as service operator.

4.8 Bluetooth:

【Power】 : Activate/deactivate Bluetooth.

【Inquiry audio device】 : Search for Bluetooth devices.

【My device】 : Display device model when connected.

【Active device】 : Display the model of online device.

【Settings】 : Setting the parameters when Bluetooth is connected.

◇ **Visibility:** Enable/disable.

◇ **Device name:** Change the displayed name of this phone device

◇ **Authentication:** Enable/disable.

◇ **Audio path:** Set voice to the phone or to handsfree device.

◇ **Location of store :** Set the path of transmission.

◇ **File transmission setting:** Set the directory and privilege of the directory.

【About】 : Introduction of the Bluetooth device.

4.9 Restore Factory Settings

You can restore some settings of the phone to factory settings. To restore the factory settings, enter the password. The default password is “1122”.

5 Multimedia

5.1 Audio player

The operating system above WIN2000 does not need to install the drivers. You need

not power-off the phone when download songs. When the phone is connected to PC, it will display USB setting interface. Press the option of “Storage device”, then the PC display the message of found new hardware and update one mobile Disc. The selected MP3 need be copied into “My Music” root directory, if it is copied into other directory it can’t be played. (The phone only supports the format of MP3, Amr and MIDI)

Descriptions of Audio Player options:

- ✧ **Play:** To play the selected MP3.
- ✧ **Details:** To view the detailed information of the selected MP3.
- ✧ **Add to tone library:** To add the selected song to the tone library for selection.
- ✧ **Refresh list:** To update the play list of songs.
- ✧ **Settings:** To set parameters for playing MP3.
- ✧ **Bluetooth forward:** To forward the selected file by Bluetooth.

5.2 Camera

With this function, you can use the built-in camera of the phone to take a photo, or adjust the camera settings. Photos generated by the camera are in JPG format. If they have been downloaded to your PC, view them with the right software!

When the phone has insufficient memory space for new photos, you should delete some old photos or other files in the "File Manager" function list to release memory space for new pictures.

- ✧ **【Photos】** : To view a saved photo.

- ✧ **【Camera settings】** : To set the corresponding parameters of the camera.
- ✧ **【Image settings】** : To set the corresponding parameters of the photo to be shot.
- ✧ **【White balance】** : Adjust the white balance.
- ✧ **【Scene mode】** : Setting the scenario mode of the camera.
- ✧ **【Effect settings】** : Setting the special effect for photo shooting.
- ✧ **【Add frame】** : Setting the picture frame.
- ✧ **【Storage】** : To set the storage directory for photos.
- ✧ **【Restore default】** : To restore the settings of camera to factory settings.

5.3 Video player

Support .avi format's video. The following operation can be performed to the selected video file of .avi format:

- ✧ **Play:** To play a video file.
- ✧ **Transfer:** To transfer a video file to the desired application.
- ✧ **Rename:** To rename a video file.
- ✧ **Delete:** To delete the selected video file.
- ✧ **Delete all:** To delete all video files.
- ✧ **Sort:** To sort video files by desired method.
- ✧ **Preferred storage:** To select the storage directory (cell phone or memory card) for a video file.
- ✧ **Bluetooth setting :** Enable or disable Bluetooth stereo output and select

Bluetooth stereo earphone.

5.4 Video Recorder

Press the red icon bottom of the screen or press OK key to start or pause video recording. The recording time is limited by the volume of the memory of the phone or the memory card. Enter the option, you can make the following settings:

- ✧ **Camcorder settings** : Setting the related parameters of the recorder.
- ✧ **Video settings** : Set the parameters of the video to be recorded.
- ✧ **Effect settings** : Set special effect to be applied when recording.
- ✧ **Storage** : It is able to choose the saving route of record file (cell phone or memory card).
- ✧ **Restore default** : Resume the consumer settings for recording to the original plant default.

5.5 Image viewer

The shot photos are stored in the image viewer.

Descriptions of image viewer options:

- ✧ **View**: To view a photo.
- ✧ **Browse mode**: To select the mode for browsing photos.
- ✧ **Transfer**: To transfer a photo to the desired application.
- ✧ **Rename**: To rename the selected image or photo.

- ❖ **Delete:** To delete the selected photo.
- ❖ **Delete all:** To delete all photos.
- ❖ **Sort:** To sort photos by the desired method.
- ❖ **Preferred storage:** To set the storage directory for photos.

5.6 Sound recorder

To make an audio record, select the “Audio Recorder”. Select the "Options" for the selected record file to perform the following operation. :

- ❖ **Record:** To make an audio record.
- ❖ **Play:** To play a selected record file.
- ❖ **Append:** Append a record to the designated files in the upper directory. (You can only append a record file in .AMR format.)
- ❖ **Rename:** To rename the selected record file.
- ❖ **Delete:** To delete the selected record file.
- ❖ **Delete all:** To delete all record files.
- ❖ **Settings:** To set the Preferred Storage, File Format and Quality for record files.
- ❖ **Forward :** Forward a sound file to a relevant application.

5.7 FM Radio

You can receive the FM Radio channel just when plugging earphone. Including the following functions:

5.7.1 FM radio

- ❖ **Channel list** : Add the user-defined channel, editing including:
“Channel name”, “Frequency” need to be set.
- ❖ **Manual input** : Input the desired broadcasting channel manually and frequency.
- ❖ **Preset auto search** : Automatically search and select the best FM.
- ❖ **Settings** : Set background play, cell phone speaker, recording format and storage device.
- ❖ **Record** : Record the current channel and store.
- ❖ **Append** : Copy the selected audio file.
- ❖ **File list** : Manage the recorded audio file.

5.7.2 Schedule FM record : Record the appointed frequency audio at the appointed time.

6 Organizer

6.1 Alarm

The time format of the alarm clock is the same with the format in the clock. The alarm clock can work even if the phone is switched off as long as there is enough power in the battery. Alarm time, snooze time-out and alarm tone can be set independently for every alarm. The phone will alarm when the time reaches the set time and current time and date will display on the screen. Press Stop to stop the alarm; press Sleep, the alarm will pause and alarm again at the snooze time-out.

Note: your phone support alarm clock when switching off. When your phone is swathed off, the alarm clock can still work as long as there is enough power in the battery.

6.2 Calendar

With this function, you can view the calendar and schedule, and you can schedule with the scheduler to set the schedule and alert. Move the cursor to the desired date with direction keys, and the date will be highlighted in light blue frame. If a memo has been set in the schedule of some date, the date bottom adds displaying of schedule icon. To view all memos of a day, move the cursor to the date. In this case, the following operation can be performed:

6.2.1View tasks : View the set schedule.

6.2.2Add task : Edit new item for a schedule.

6.2.3Jump to date : Move the cursor to the calendar of the specified date.

6.2.4 Go to weekly view: To view the set schedules by week or month.

6.3 E-Book Reader

E-book application can help you to read a file that stored in phone or memory card in .txt format.

❖ **Open:** To open an E-book.

❖ **Update:** To Update an E-book.

❖ **System presetting:** To set the attributes of an E-book.

❖ **Information:** To view the attributes of a text.

- ✧ **Delete:** To delete a text.
- ✧ **Delete all:** To delete all texts.
- ✧ **Sort:** To sort E-books in a folder.
- ✧ **Apply:** To apply the settings.
- ✧ **Help:** To open E-book help description.

6.4 Calculator

- ✧ Eight operators, i.e. “+”, “-”, “×”, “÷”, “m+”, “m-”, “mc”, and “mr”, are provided.
- ✧ Choose the Clear or press the right soft key to clear items entered. Long press the Clear or long press the right soft key to clear all content. Press the “Ok” to show the result of calculation.

Note : The accuracy of this calculator is limited, and the calculator can only be used in simple calculation.

6.5 Stopwatch

Your phone supports ordinary stopwatch and multifunctional stopwatch. You can time, time by lap and view record, etc.

6.6 To do

For creating a new memo or viewing the memos set in the schedule. You can also perform View, Add, Edit, Delete Entry, Delete All and Transfer Date book, etc. If the alarm reminder is set up for the memo, the cell phone will remind you with

ring once the time is up, and it will display the contents of the memo settings.

6.7 World clock

View the corresponding to the time zone of countries in the world by the direction keys.

6.8 Unit Converter: User can use this option to convert different units.

7 File Manager

Phone : Support phone memory to save user data, phone memory is limited.

Memory card : The phone will perform this option if the memory card (T-Flash) is installed.

Folders or files in the memory card or the phone can be managed by the files management template.

- ✧ **Open** : To open the selected file stored.
- ✧ **New folder** : To create a folder.
- ✧ **Rename** : To rename a folder.
- ✧ **Delete** : To delete the designated file.
- ✧ **Sort by** : To sort files by the desired type.

8 Service

8.1 STK (SIM Tool Kit)

STK is a value added service provided by your network provider.

The display of function menu may differ according to different SIM cards.

8.2 WAP

This function allows you to acquire or visit diversified services on the Internet through message or network. The services may include entertainment, weather forecast, news, financial information, ring tone download, stock market and other useful information. Some functions are provided by the network provider. You will see different menus according to the services provided by the SIM card. Please contact your network provider for more information.

【Homepage】 : Enable WAP connection and visit the home page..

【Bookmarks】 : Visit or edit the bookmark.

【Recent pages】 : Record the recently visited web addresses.

【Offline pages】 : View the saved web pages.

【Input address】 : Provide user-defined inputting web address.

【Service inbox】 : Save the PUSH messages received by the phone.

【Settings】 : Set parameters of WAP browser. Please consult your network provider for details of the parameters.

- ❖ Select SIM : Those options include “always inquire, SIM card 1 and SIM card 2”.
- ❖ Edit profile: To edit and enable the profile function.
- ❖ Browser options: To set the wait time and whether to show images. Display the address list and select image can be performed.
- ❖ Service message settings: Enable or disable.

- ❖ Clear cache: It may reduce speed of internet connection when there are too much data stored in the cache.
- ❖ Clear cookies: Delete all personal information.
- ❖ Trusted certificates: To view the trusted certificates provided by the system.

8.3 Data account :

GSM data——Some account data will be provided by GSM data, user need to set this data as per the network provider settings.

GPRS——Using GSM data will provide some account information

Note:

- ❖ Please consult local network service provider for charging standard and specific settings.
- ❖ User may consult local network provider for GPRS settings & GPRS activation. The network settings vary for the different network provider.

9 Games

Provide you interesting and classical games. Please refer to help of the game for specific operation.

VII. Operating instructions of editor

Your phone provides you with different input methods for the convenience of using other function. You can enter texts by keypad at anywhere requiring entering texts. Enter setting > Phone setting > Default input method to choose a default input method.

Input interface key function

Press corresponding key under input interface, for example of writing message.

Numeral 1 to 9 is used to edit text contents.

Direction keys : Control the movement of cursor.

key : Switch the input method.

* key : Enter the selecting of symbol.

Hang-up key : Retreat from the edit interface.

Smart English input

Press the numeral keys 2 to 9, the letters contained in the number and the corresponding number will appear on the screen.

Enter a word

Under smart English input method, continuously press 2 to 9 keys for twice or more, the corresponding word will appear on the screen.

For example, if you want to enter “book”, press the numeral keys “2665”, and then select the word “book”. You can press the 0 key to enter a space when you need.

Figure input

Press the corresponding key to input the corresponding number.

Symbol input

Press * key to into the interface of inputting symbol, when the phone not under the interface of symbol. Transfer direction keys to move the cursor to desired symbol, press OK key to select it.

Handwriting input

The phone support handwriting, you can handwriting under input interface. Before input, you can press the icon of “abc” etc or press # key to change the input method. Write words in the inputting field by handwriting pen.

VIII. Application of USB storage function**Precautions before using**

- ✧ Please maintain correct operation of USB equipment connection and disconnection.
- ✧ Please don't use windows formatting command to carry on the format operation to the mobile disk of cell phone; otherwise, it will result in the damage that can't be repaired any more.
- ✧ USB operation environment :

- ◇ windows2000 / XP.
- ◇ For other operating systems, it may require the installation of USB driver before successfully creating the connection of PC and cell phone.

IX. Appendix 1

Troubleshooting

Failure	Possible cause
The phone fail to power on	1、 Check that the battery is charged; 2、 Check that the battery is installed correctly.
SIM card error	1、 Check whether the SIM card is dirty. If the card is dirty, clean it ; 2、 Reinstall the SIM card ; 3、 If the SIM card is damaged, replace the SIM card.
Weak signal	Check that the signal intensity indicator on the screen. 4 bars indicate a strong signal, and 2 bars or less indicate a weak signal.

Call initiation fails	<p>1、 You may set the Hide Caller ID but the network operator does not support this service ;</p> <p>2、 A strong signal interference may exist ;</p> <p>3、 You may activate the Call Barring function ;</p> <p>4、 You may activate Line 2 but the network operator does not support this service.</p>
Battery charge fails	<p>1、 The battery may have been excessively discharged. To charge the battery, it is necessary to connect it to a charger for a certain period of time ;</p> <p>2、 The battery may be deteriorated.</p>
Cannot connect to the network	<p>1、 Check whether the signal is too weak or wireless interference exists around ;</p> <p>2、 Check whether the SIM card is installed correctly, poor connection exists, or the SIM card is damaged. If the SIM card is damaged, please contact the network operator.</p>
Photos shot too dark	<p>1、 The brightness is set too low ;</p> <p>2、 The ambient light is too dark.</p>
Photos shot too blurred	<p>1、 The object shot is moving ;</p> <p>2、 Your hand shakes when the shutter is pressed.</p>
Photos shot is distorted	The object shot is too near to the lens.

Cannot access the service menu	The SIM card may not support the service.
The standby picture can't be displayed integrally.	Maybe the picture is extra of the size. It is recommended that the standby picture size to be 240*320

X. Appendix 2

Abbreviations

SMS	Short Message Service
EMS	Enhanced Message Service
SIM	Subscriber Identity Module
GSM	Global System for Mobile Communication
PIN	Personal Identity Number
PUK	PIN Unblocking Key
IMEI	International Mobile Equipment Identity

CB	Cell Broadcast
GPRS	General Packet Radio Service
MMS	Multimedia Message service